

# WIND & WATER LEAKS

1. Turn on vehicle's HVAC blower (set to 'Fresh Air').  
(This creates positive cabin pressure)
2. Connect unit's 'smoke diffuser' to supply hose.
3. Lay smoke path along seals.

(Note: The UltraTraceUV® dye in the smoke will not be deposited on components when used in this manner and is not harmful in any way)

***Notice smoke path disturbance  
at point of leak.***

